



QCOAT

OUTDOOR TIMBER OIL

PENETRATES | PROTECTS | STABILISES



- ✓ EASY TO MAINTAIN - NO SANDING
- ✓ COATING DOESN'T CRACK OR PEEL
- ✓ ENRICHES NATURAL TIMBER COLOUR

- ✓ FAST & EASY TO APPLY
- ✓ NO WEATHERING REQUIRED
- ✓ AUSTRALIAN MADE

www.iconictimber.co.nz

PREPARATION

- ◆ All surfaces must be well prepared and free from dirt, oil, grease, mould and other contaminants.
- ◆ Previously coated timber requires complete stripping back to bare timber to allow Qcoat oil to penetrate.
- ◆ Where external timber has completely greyed in colour, the timber should be rejuvenated either by sanding or using a propriety timber cleaner. All moss, algae, lichen etc must be completely removed using chlorine bleach or a propriety mould treatment. Use according to package directions.
- ◆ When the timber has faded to a pale colour or water is not beading on the surface, simply re-apply Qcoat to the clean, dry surface. Severely weathered surfaces need additional treatment as per above.

APPLICATION

NOTE: New timber should be coated on all 4 sides before installation.

1. Calculate quantity of oil required:
 - a. For pine allow 10-12m² per liter.
 - b. For hardwood allow 6-8m² per liter.
 - c. The 2nd coat will require less oil.
2. Stir the oil thoroughly before using a wide flat stirrer, ensuring the bottom of tin is reached.
3. Use a brush or wool applicator to evenly spread the coating onto timber – wipe off excess material 1-2 hours after application.
4. Take time to ensure cut and exposed ends are thoroughly soaked to minimize water penetration.
5. Allow 6-8 hours for oil to dry before applying 2nd coat.
6. After the 2nd coat allow a further 24 hours before walking on.

TIP: To avoid overcoating the timber (oil becomes tacky), add mineral turpentine to the oil (up to 20% of your oil qty), this will increase timber absorption of the oil.

MAINTENANCE

NOTE: Each coat is cumulative and builds up additional stability & protection.

- ◆ Re-coating time depends on usage and weather exposure.
- ◆ If water stops beading on the surface, a recoat is required.

SAFETY

- ◆ Keep out of reach of children.
- ◆ Avoid contact with skin and eyes.
- ◆ Ensure the coating area is well ventilated.
- ◆ Wear appropriate personal protection equipment.
- ◆ Keep away from potential sources of ignition - Qcoat is solvent based and flammable.

FIRST AID

- ◆ Contact Poisons Information Centre on 0800 764 766.
- ◆ If swallowed, do NOT induce vomiting. Drink a large glass of water and immediately seek medical advice.
- ◆ If in eyes, flood with water for 15 minutes, then seek medical advice promptly.
- ◆ If skin contact occurs, wash thoroughly with soap and water.



Qcoat is a penetrating timber oil formulated to protect outdoor timber from the effects of weathering by repelling moisture and improving dimensional stability. Qcoat is specially designed for use with outdoor timber projects such as decks, boardwalks, jetties, bollards, fences and park furniture. Suitable for use with all timber species, Qcoat brings out the warmth and beauty of real natural timber.

www.iconictimber.co.nz